



Good! There is plenty of space to print on the top and bottom, easily avoiding the small amount of logo text on the sides



Bad! This label will have large holes in it due to the shiny "MAGNAVOX" and "CD-R" letters

Center for Teaching, Learning, and Technology

1021 Dulaney Valley Road
Baltimore, Maryland 21204
Phone: 410-337-6066
E-mail: ctlit@goucher.edu

Center for Teaching, Learning, and Technology
ctlit@goucher.edu

x6066

CD/DVD Disc Title Printer



USING THE DISC TITLE PRINTER

WARNING!

Before you start, make sure of these two things!

- 1. Create your label on a disc that you have NOT YET BURNED. The disc title printer may damage existing data.**
- 2. Create your label on a disc that DOES NOT have any shiny writing, lines or logo over the area you wish to label! These areas are unprintable! (See opposite side for clarification)**

Basic Steps for Using the Printer

1. Press the blue "ON" button in the top left corner.
2. Press "SET" to select "NEW"
3. Using the arrow keys, select a pattern. This indicates which orientation you would like the label to be printed.
4. Select a format. This will determine the layout of the text within the title. Press "SET" to select a format. For instructions on using "logo" or "frame" layouts, see rightmost column.
5. Enter text, one box at a time. Note that each box has a character limit.
6. Press "SET" to move on to the next textbox, or complete the label if the current textbox is the last textbox
7. Press "ESC" to return to the previous textbox and correct any mistakes
8. When the "PRINT/STORE/EXIT" menu appears, press "SET" once more to confirm that all text was entered properly
9. Slide the disc into the printer in the orientation shown on the screen and press "SET"
10. If you would like to label another disc using the same label design, select "PRINT" again. To start over and create a new label, select "EXIT."
11. Press "OFF" when all label-making is complete.

Adding Large Images

When selecting a format, there are several formats labeled "logo" and "frame"

1. The "LOGO" option allows you to choose one of twelve different large, premade images for your label. These will be placed in the checkered box within the format
2. The "FRAME" option allows you to choose one of fourteen different themed frames for your text. They each include a small image on the left side, plus a border for the textbox

Adding Small Images

While typing in text, there are several options for non-standard characters

1. The "ILLUST" button brings up a menu with 124 different illustrations of household objects, faces, street signs, and more
2. The "SYMBOL" button brings up a menu with four submenus, each of which has dozens of non-English characters and other symbols
3. The "USER CHR" button allows the user to draw a picture using a simple pixel-by-pixel black and white drawing program.